



THE BATTERY INTELLIGENCE COMPANY



INNOVATIVE SOLUTIONS FOR LITHIUM ION BATTERY FUTURE DEVELOPMENT

Rachid Yazami



21/8/2019

Outline

- A brief introduction to entropymetry
- Applications of entropymetry
- Fast charging methods
 - “Natural charging”, Non-linear Volammetry (NLV)
 - “Cascade Pulse Charging” (CPC)
- Summary

A brief introduction to entropymetry

- Basic equations:

$$\Delta G(x) = \Delta H(x) - T\Delta S(x)$$


$$\Delta G(x) = -nFE^0(x)$$

$E^0(x)$ =OCV at any SOC 'x'

$$\Delta S = nF \frac{\partial E^0(x)}{\partial T}$$

$$\Delta H = -nF \left(E^0 - T \frac{\partial E^0(x)}{\partial T} \right)$$


ETMS: BA-2000 Equipment






Potentiostat-
Galvanostat
System

Laptop: Control
&
Management

Battery Holder &
Temperature Controller



Entropymetry in 3 steps



Entropy and enthalpy show more variations than OCP


Applications of entropymetry

21/8/2019

Confidential



1. Chemistry recognition, QC



2. SOC assessment


The Universal Battery SOC Law

$$SOC = \alpha + \beta \Delta S + \gamma \Delta H$$


- This law applies to all tested chemistries, including
 - LIB, NiCd, NiMH,
 - Li-MnO₂, Li-FeS₂
 - Alkaline Zn/MnO₂ and Zn/C cells
- α , β and γ depend on the cell' chemistry and on SOH

1. Alkaline Zn/MnO₂ cells

SOC- ΔS - ΔH 3D plots



SOC simulation



$$\alpha = -621.76$$


$$\beta = 0.3708$$

$$\gamma = -4.510$$

$$R^2 = 0.973$$

2. ZINC /CARBON DRY CELL

SOC simulation



$$\alpha = -383.19$$

$$\beta = 1.595$$


$$\gamma = -3.414$$

$$R^2 = 0.987$$

3. Lithium (primary) cells

a. Li/MnO₂ cells

3D plots




$$\alpha = -1800$$

$$\beta = 1.611$$

$$\gamma = -6.627$$

$$R^2 = 0.9982$$

b. Li-FeS₂ cells



$$\alpha = 167$$

$$\beta = 0.8$$


$$\gamma = 0.2$$

$$R^2 = 0.98$$

2. RECHARGEABLE CELLS


a. Lithium Ion Batteries

SOC- ΔS - ΔH 3D plots




SOC Simulation

$$\text{SOC} = \alpha + \beta\Delta S + \gamma\Delta H$$



Linear relationship applies to all LIB chemistries




SOC fitting parameters for # LIBs


Battery #	α	β	γ	R ²
1	-471.6797	0.4299	-1.4449	0.989
2	-422.2317	0.7183	-1.3116	0.996
3	-438.1669	0.3607	-1.3688	0.991
4	-445.4292	0.6906	-1.3734	0.994
5	-423.5349	0.4894	-1.3335	0.994

b. Ni-MH

SOC- ΔS - ΔH 3D plots Ni-MH



SOC Simulation



Battery #	α	β	γ	R^2
1	-503.7	8.5	-3.8	0.85


3. SOH assessment

α, β and γ depend on SOH



Cycle # (55 °C, 1C-rate)	SOH (%)	α	β	γ	R ²
0	100	-523.56	0.31312	-1.6159	0.99+
50	97.7	-453.82	0.08161	-1.4162	
100	92.9	-438.82	0.15153	-1.3736	
150	91.5	-417.76	0.024905	-1.3119	
200	89.5	-414.18	0.081835	-1.3004	
50	88.5	-432.2	0.15816	-1.3561	
300	86.6	-390.2	0.095205	-1.2439	
350	84.7	-434.42	0.18258	-1.3638	

4. SOS assessment

Internal short-circuit model for thermal runaway




y a court-circuit.



4. SOS assessment


Internal Short-Circuit Detection

OCV vs SoC




4. SOS assessment

Enthalpy vs OCV (Average)




4. SOS assessment

Entropy vs OCV (Average)



The Imbedded Chip for online SOC, SOH and SOS online assessment



21/8/2019

Confidential




5. Fast charging: beyond CCCV

a. Non-linear voltammetry (NLV)

Solving a differential equation:


$$\phi \left(i, v, \frac{\partial i}{\partial t}, \frac{\partial v}{\partial t}, \text{SOH} \right) = 0$$

Typical current, voltage, capacity profiles during NLV charging




Charge-discharge profiles


NLV Only Charge & Discharge Profile
36 Mins (Avg)




Charge profile may be different at each cycle



Intermittent NLV charge profile




Temperature Profile



5. Fast charging: CPC


b. Cascade Pulse Charge




21/8/2019

Confidential

CPC in 10 min: voltage profile



Introduction: electrode processes in LIB



Theoretical lithium composition in anode and cathode in a C/LCO cell

	Charge state	Discharge state	Capacity (mAh/g)
Graphite anode	LiC_6	Li_0C_6	372
LCO cathode	$\text{Li}_{0.5}\text{CoO}_2$	LiCoO_2	138

Ideal cell reaction:



Theoretical lithium composition in anode and cathode vs. SOC of a C/LCO cell

X=SOC of the full cell,

$$0 \leq X \leq 100\%; \quad 0 \leq x = \frac{X}{100} \leq 1$$

- Anode composition: Li_xC_6
- Cathode composition: $Li_{1-\frac{x}{2}}CoO_2$

Question: What is the actual Li composition in anode and cathode vs. SOC in a real cell?

- Anode composition: $Li_{f(X)}C_6$,
- Cathode composition: $Li_{g(X)}MO_2$,

What is $f(X)$?, $g(X)$?

A very simple question,

NO EXISTING ANSWER TODAY !

Why no answer?

- There are 4 unknowns

x_{min}, x_{max} and y_{min}, y_{max}

- Cathode: $x_{min} < g(X) < x_{max}$ in Li_xMO_2
 - Anode: $y_{min} < f(X) < y_{max}$ in Li_yC_6
- We need 4 independent equations
 - OCV vs. SOC gives 1 equation
 - 3 equations are missing

Approach


At any SOC 'X' of a full cell, the following equations apply:

Free energy	$\Delta G(cell) = \Delta G^+ - \Delta G^-$
Open-circuit potential	$E_0(cell) = E_0^+ - E_0^-$
Entropy	$\Delta S(cell) = \Delta S^+ - \Delta S^-$
Enthalpy	$\Delta H(cell) = \Delta H^+ - \Delta H^-$

- Measure OCP, entropy and enthalpy in half-cells and in a full cell
- Fit OCP, entropy and enthalpy data vs. SOC
- Fit entropy and enthalpy data vs. OCP
 - Determine $\alpha_{ca}, \beta_{ca}, \alpha_{an}, \beta_{an}$ in the 2 equations




$$g(X)=x = \alpha_{ca}X + \beta_{ca}$$

$$f(X)=y = \alpha_{an}X + \beta_{an}$$




$x_{min}, x_{max}, y_{min}, y_{max}$




1. OCP profiles




1. OCP mismatch






2. Entropy profiles




2. Entropy mismatch




3. Enthalpy profiles




3. Enthalpy mismatch



Mismatch reduction by iterative computation







Mismatch reduction in aged cells (300#, 55 °C)




Computed parameters for fresh and aged cells

Sample		Fresh	HT100	HT200	HT300	RT100	RT300	RT500
Capacity (mAh/cm ²)	Cathode	2.28	2.11	1.94	1.99	2.31	2.28	2.18
	Anode	1.84	2.23	1.91	2.05	2.11	1.94	1.99
Fitting parameter s	α_c	0.91	1.32	1.23	1.00	1.24	1.08	1.10
	β_c	9.49	-19.15	-19.80	1.17	-10.19	0.71	-6.25
	α_a	0.82	0.95	1.12	0.78	1.15	1.01	0.92
	β_a	-1.75	-14.96	-24.18	-20.86	-32.06	-29.18	-1.53
Calculated parameter s	a	0.41	0.44	0.37	0.31	0.47	0.40	0.38
	b	0.88	0.98	0.98	0.92	0.96	0.92	0.94
	c	0.39	0.55	0.56	0.41	0.63	0.51	0.48
	d	0.10	0.12	0.06	0.23	0.10	0.14	0.05
Lithium compositio n range	x_{max}	0.88	0.98	0.98	0.92	0.96	0.92	0.94
	x_{min}	0.47	0.54	0.61	0.60	0.49	0.52	0.56
	y_{max}	0.49	0.67	0.62	0.64	0.73	0.65	0.53
	y_{min}	0.10	0.12	0.06	0.23	0.10	0.14	0.05

Lithium composition ranges in anode and cathode



Cell Regeneration




x_{\max}	0.92
x_{\min}	0.60
y_{\max}	0.62
y_{\min}	0.06


Summary

- A new method for accurate assessment of lithium composition in anode and cathode has been developed for the first time
- The method is based on ETM + data computation to reduce mismatch between full-cell and half-cells data
- Anode and cathode were found to operate with a relatively low utilization rate ~50-75%
- The method can be used to improve battery performances during manufacturing
- Anode and cathode performance decay differently according to ageing conditions

The Smart CHIP




- One Chip for each fast charger



Artificial Intelligence Technology

Connected Objects
A Brain in Each Charger



Summary

- Entropymetry addresses major battery issues including
 - Chemistry, SOC, SOH and SOS
- Two ultra-fast charging methods have been developed:
 - NLV (natural charging in ~ 20 min)
 - CPC (possibly in ~10 min)
- These new methods are safe and allow for long cycle life (>1300#)



Thank you

Rachid@kvi-battery.com

